

Easy Grill Scraper™ N55825 OPERATING INSTRUCTIONS

<u>Important</u>

- 1. To get the best operation and life from your machine, please read and comply with these instructions.
- 2. Clean scraper thoroughly before and after all uses using cleaning instructions below
- 3. Minimize the use of alkaline cleaners as they may cause pitting and dulling of the finish.

OPERATION

- 1. Hold the Easy Grill ScraperTM with one hand on the handle and one hand on the knob.
- 2. Place blade on grill.
- 3. Clean grill by pushing down and forward.

CLEANING

NOTE: Proper maintenance plays an important part in the life span and functioning of the unit

- 1. Spray off scraper after heavy usage.
- 2. Wash scraper in hot, soapy water.

| 55606 HANDLE |
|--|
| 55608 SPLASH GUARD |
| |
| 55607-6 SCRAPER BLADES PACK OF 6 |
| 451 40 SCREW (2) 451 51 LOCK WASHER (2) 45086 WING NUT (2) |



301 Meuse Argonne, Hicksville, OH 43526

Fax: 419-542-6690 www.nemcofoodequip.com

NEMCO FOOD EQUIPMENT

Phone: (419) 542-7751

Toll Free: 1-800-782-6761

45881 8/09/04